

# INSTALLATION PROCEDURE



## Wabo®TransFlex Joint System

Molded Rubber Segmental Expansion Joint System for Bridge & Highway Applications

---

### A. General

The work shall consist of furnishing and installing a Wabo®TransFlex joint system in accordance with the details shown on the plans and the requirements of the specifications. The Wabo®TransFlex joint system is shipped in standard sections, 6'-0" lengths (4'-0" lengths for TransFlex 1300). The molded neoprene monolithic units are reinforced with steel angles and imbedded wear plates, which are tongue-and-grooved for field assembly.

### B. Field Preparation

The blockout in the roadways, curbs, sidewalks, and barriers shall be constructed to the dimensions shown on the shop drawings. All air voids 1/4" (6 mm) and larger shall be pointed with an approved grout. The bottom surface of the blockout shall be parallel with the plane of the roadway (true and flat).

The anchor spacing, corresponding to the dimensions spanning the open joint, must be verified and adjusted for temperature prior to the installation of the anchors.

### C. Anchor Placement

Cast-in-place type anchors (New Installation) and Chemical type anchors (Rehab), shall be installed into the formwork starting at the gutterline and proceeding toward the "field-cut piece." Care shall be taken to ensure that the anchors are set at right angles to the bottom of the blockout.

### D. Panel Installation

Starting at the curb sections, position the NP1 Sealant bedding material as shown on the shop drawings. Place fabricated curb into blockout and install fastening hardware.

Place a 2 x 4 against the second set of anchors from the curb piece as a base for the jack. Adjust the jack to fit into the blockout and place another 2 x 4 against the end section of the curb piece. Compress the curb section and tighten nuts to the specified torque noted on the shop drawings.

Apply NP1 Sealant to the tongue or groove ends of the fabricated curb and install first roadway section over the anchors and force adjacent blocks against the previously installed curb assembly. Continue this procedure with the standard sections until reaching the field-cut piece.

After field measuring, cut the designated field-cut piece or pieces to the required dimension. Apply NP1 Sealant to the cut ends. Approximately one hour after initial placement, all nuts or bolts shall be retorqued.

With all sections installed to the satisfaction of the Engineer, fill the bolt cavity with URA Sealant.

Seal void between Wabo®TransFlex sections and vertical face of blockout with NP1.