


• Represents Contact points when assembling drainage boot. The Dots must be touching and bonded for a proper assembly.

--- = Fold Lines
 — = Cut Lines

Material: 1/32" Thick Neoprene Sheetgood. (WBA P/n: 6300)



Notes:

1. Overall width of Boot Transition will be determined on the amount of movement the WSW system can accommodate during normal movement ranges. WBA suggests that the dimension will be at least Maximum Opening plus 1". This is to ensure that there will not be any damage to the boot while the system is at maximum opening.

PROJECT NAME: -

PROJECT LOCATION: -

DRAWING DESCRIPTION:

Wabo®WeatherSeam
 WSW Termination Boot

DATE: 01/25/2021

MODEL: WSW



Watson Bowman Acme
 95 Pineview Drive Amherst, NY 14228
 phone: (716) 691-7566 fax: (716) 691-9239
 www.watsonbowmanacme.com

A brand of
MBCC GROUP

Information provided herein, including but not limited to, any drawing, design, photograph, graphic, or statement(s) ("Materials") are proprietary and the property of Watson Bowman Acme Corporation ("Company"). Reproduction, translation, or reduction to any electronic medium or machine readable form, in whole or part, is strictly prohibited, except for the express purpose for which it has been furnished, without prior written consent of Company. All Materials contained herein are provided by Company for information purposes only. Company reserves the right to amend or withdraw any information contained in the Materials without notice. All technical or other advice by Company, whether verbal or written, concerning products, or the use of products in specific situations ("Advice") is given by Company and is used at the Users own risk.

REVISION NO:

1

SHEET NO:

1

DRAWING NO:

A-26455